


Installation Instructions


1. A menu popup showing “low ink” or “used cartridge” on installation is typically not a product quality problem or concern. These messages arise because of slight incompatibilities between products created by different manufacturers.

2. Based on your printer, sometimes the actual ink volume will not be displayed through your monitor. Despite it not showing ink volume, you should still be able to continue printing as usual as if there is enough ink in the cartridge.


Operation Steps




1. Install the cartridge into the printer and the printer should display full ink levels.




3. If the printer indicates that the ink has been fully expended, please follow the prompts in the following few pictures and directions.



5. If the printer prints out blank sheets or light printing, the cartridge ink has probably been fully expended.



2. If the printer shows low ink level on a new cartridge, please disregard the message and continue trying to print as usual.



4. Press and hold the “Stop/Reset” button for about 5 seconds. This should allow the printer to function normally again.

